

# 101437 / 86979.01

No.	Description of Spare Part
1	Screw Cover Of Door Hinge
2	Door Hinge Cover
4	Upper Door Hinge
6	Thermostat controller
6.1	Thermostat
6.11	Thermostat Knob
6.3	Incandescent bulb
6.5	Controller Shell
6.6	Lamp Cover
6.7	Light Holder
17	Door Switch
19	Door
19.1	Door Gasket
19.2	Right Limit Block
20	Left Limit Block
24	Lower Balcony
25	Upper Balcony
26	Crisper Drawer Assembly
27	Cover Of Crisper Drawer
28	Fridge Shelf Assembly
29	Lower Door Hinge, Right
32	Compressor Bracket
33	Power Supply Cord Plug
35	Connecting Wire Of Compressor
36	Earthing Wire Of Compressor
37	Compressor
38	Process Tube
39	Connecting Tube
40	Drain Pan
42	Drier Filter
43	Higher Foot
47	Shorter Foot
49	Installation seat of control board
50	Electric control board
51	Cover of control board
300	Trademark
301	Carton

**Bei spezifischen Fragen zu Ersatzteilen kontaktieren Sie bitte den Kundendienst unter 0848 000 120.**

**Pour toute question spécifique concernant les pièces de rechange, veuillez contacter notre service clientèle au 0848 000 120.**

